


# PREMIUM

## Installation on Drywall or similar materials

**NOTE: follow all safety precautions and wear all safety equipment necessary before starting.**

1. Premium Slatwall can be cut to the desired length using an electric saw with a thin sharp blade.


2. Mark on the wall (or on the floor) where you want the installation of the Premium Slatwall to begin (see Figure 1) .



**Figure 1. PREMIUM SLATWALL® before fastening**

3. Locate the studs and fasten the Premium Slatwall (see Figure 2) . Make sure the Premium Slatwall is leveled before fastening (see Figure 1) .

4. Install the following Premium Slatwall panels on top of the first level panel. Continue the installation of the panels until complete. Premium Slatwall can also be cut horizontally.




**Figure 2. PREMIUM SLATWALL® installation.**

# PREMIUM

## Installation on Concrete or similar materials


**NOTE: follow all safety precautions and wear all safety equipment necessary before starting.**

1. Premium Slatwall can be cut to the desired length using an electric saw with a thin sharp blade.
2. Mark on the wall (or on the floor) where you want the installation of the Premium Slatwall to begin (see Figure 1).



**Figure 1. PREMIUM SLATWALL® before fastening**

3. Pre-drill the surface at the desired locations with a maximum separation of 16 inches. Fasten the Premium Slatwall (see Figure 2). Make sure the Premium Slatwall is leveled before fastening (see Figure 1).
4. Install the following Premium Slatwall panels on top of the first level panel. Continue the installation of the panels until complete. Premium Slatwall can also be cut horizontally.



**Figure 2. PREMIUM SLATWALL® installation.**